

IBM CARD CODE		DIGIT PUNCH												
		NO	0	1	2	3	4	5	6	7	8	9	3-8	4-8
ZONE PUNCH	12	&		A	B	C	D	E	F	G	H	I	•	⌘
	11	-		J	K	L	M	N	O	P	Q	R	\$	*
	0			/	S	T	U	V	W	X	Y	Z	,	%
	NO	BLANK	0	1	2	3	4	5	6	7	8	9	#	@